

gama.professional iQ perfetto

TO ENSURE THAT YOUR IQ HAIR DRYER CONTINUES TO FUNCTION SMOOTHLY, WE RECOMMEND DAILY CLEANING. THE HAIR DRYER IS EQUIPPED WITH A SELF-CLEANING FUNCTION TO CLEAN THE INTERNAL COMPONENTS.


1 With the hair dryer switched off, gently turn the external filter counterclockwise and pull it out. Then press and hold down the speed setting button for 5 seconds.

2 The motor will be turned on in reverse for 15 seconds while the other buttons are off.

3 Re-attach the external filter at the end of the self-cleaning function and turn the hairdryer on again.

! To interrupt the self-cleaning function, turn the hairdryer on by flicking the ON/OFF switch from O to I.

The self-cleaning function will be automatically cancelled and the hairdryer will function as normal.



Distributed by:

Gieseke cosmetic GmbH · Auf dem Kessellande 1 · 30900 Wedemark

Telephone: 05130 58 60-0 · Fax: 05130 58 60-225

INT 2111